TRAVEL

Instructions:

S-board is a plug and play keyboard device. However, to enable all functions to work properly, the software settings should be as follows:

- Choose as model / layout: US-International
- Choose as language: English-US

Depending on the operating system / Windows version, these settings can be adjusted using:

- Start/Settings/Control Panel/Keyboard
- Start/Settings/Control Panel/Regional and Language Options

If 'US-International' is not displayed, you might need to use the 'Add' button to select and add this option.

Special keys/Functions:

Num Lock on/off	Press both keys **Fn + Insert** simultaneously If num lock is activated: the num lock led will illuminate, indicating alpha keys have the numeric function, e.g.: J = 1, K = 2, L = 3, etc.
€	**Alt + 5** (If this does not work properly, you may need to adjust the Keyboard and/or Language Settings, as described above)
Sys rq	**Fn + prt sc**
Scroll Lock	**Fn + delete** (scroll lock led will illuminate)
Symbols	**Num Lock + Alt + code** Example: Num Lock + Alt + 'JL7' = ë (using num lock JL7 = 137)